

UNCLASSIFIED


~~Prater~~ **RR1**
LO
BC
AEROSPACE REPORT NO.
ATR-81(8430)-1

Development of Laser Mirrors of Very High Reflectivity Using the Cavity-Attenuated Phase-Shift (CAPS) Method

Prepared by
J. M. HERBELIN and J. A. McKAY
Aerophysics Laboratory

5 August 1981

Prepared for
VICE PRESIDENT AND GENERAL MANAGER
LABORATORY OPERATIONS



Laboratory Operations

THE AEROSPACE CORPORATION

PLEASE RETURN TO:

BMD TECHNICAL INFORMATION CENTER
BALLISTIC MISSILE DEFENSE ORGANIZATION
7100 DEFENSE PENTAGON
WASHINGTON D.C. 20301-7100

U3866

DTIC QUALITY INSPECTED 4

19980309 351

UNCLASSIFIED

LABORATORY OPERATIONS

The Laboratory Operations of The Aerospace Corporation is conducting experimental and theoretical investigations necessary for the evaluation and application of scientific advances to new military concepts and systems. Versatility and flexibility have been developed to a high degree by the laboratory personnel in dealing with the many problems encountered in the Nation's rapidly developing space systems. Expertise in the latest scientific developments is vital to the accomplishment of tasks related to these problems. The laboratories that contribute to this research are:

Aerophysics Laboratory: Aerodynamics; fluid dynamics; plasmadynamics; chemical kinetics; engineering mechanics; flight dynamics; heat transfer; high-power gas lasers, continuous and pulsed, IR, visible, UV; laser physics; laser resonator optics; laser effects and countermeasures.

Chemistry and Physics Laboratory: Atmospheric reactions and optical backgrounds; radiative transfer and atmospheric transmission; thermal and state-specific reaction rates in rocket plumes; chemical thermodynamics and propulsion chemistry; laser isotope separation; chemistry and physics of particles; space environmental and contamination effects on spacecraft materials; lubrication; surface chemistry of insulators and conductors; cathode materials; sensor materials and sensor optics; applied laser spectroscopy; atomic frequency standards; pollution and toxic materials monitoring.

Electronics Research Laboratory: Electromagnetic theory and propagation phenomena; microwave and semiconductor devices and integrated circuits; quantum electronics, lasers, and electro-optics; communication sciences, applied electronics, superconducting and electronic device physics; millimeter-wave and far-infrared technology.

Materials Sciences Laboratory: Development of new materials; composite materials; graphite and ceramics; polymeric materials; weapons effects and hardened materials; materials for electronic devices; dimensionally stable materials; chemical and structural analyses; stress corrosion; fatigue of metals.

Space Sciences Laboratory: Atmospheric and ionospheric physics, radiation from the atmosphere, density and composition of the atmosphere, aurorae and airglow; magnetospheric physics, cosmic rays, generation and propagation of plasma waves in the magnetosphere; solar physics, x-ray astronomy; the effects of nuclear explosions, magnetic storms, and solar activity on the earth's atmosphere, ionosphere, and magnetosphere; the effects of optical, electromagnetic, and particulate radiations in space on space systems.

Accession Number: 3866

Publication Date: Aug 05, 1981

Title: Development of Laser Mirrors of Very High Reflectivity Using the Cavity-Attenuated Phase-Shift (CAPS) Method

Personal Author: Herbelin, J.M.; McKay, J.A.

Corporate Author Or Publisher: Aerospace Corporation, Laboratory Operations, El Segundo, CA 90245 Report Number: ATR-81(8430)-1

Report Prepared for: Air Force Weapons Laboratory, Kirtland AFB, NM 87117 Report Number Assigned by Contract Monitor: SLL 83-U-027

Comments on Document: Archive, RRI, DEW

Descriptors, Keywords: Development Laser Mirror Very High Reflectivity Cavity Attenuate Phase Shift CAPS Chemical Kinetics Substrate Procurement Cleaning Quartz Scatter Measurement Dielectric Coating

Pages: 00017

Cataloged Date: Nov 20, 1992

Contract Number: F04701-80-C-0081

Document Type: HC

Number of Copies In Library: 000001

Record ID: 25155

Source of Document: DEW

DEVELOPMENT OF LASER MIRRORS OF VERY
HIGH REFLECTIVITY USING THE
CAVITY-ATTENUATED PHASE-SHIFT
(CAPS) METHOD

Prepared by
J. M. Herbelin and J. A. McKay
Aerophysics Laboratory

5 August 1981

Prepared for
VICE PRESIDENT AND GENERAL MANAGER
LABORATORY OPERATIONS

THE AEROSPACE CORPORATION
El Segundo, Calif. 90245

ABSTRACT

It has been possible to obtain mirrors of very high reflectivity by following the simple four-step procedure described herein. The key to success is the ability to measure the scattering and other losses of the substrates and dielectric coatings to ensure that the specifications are being met. These measurements are especially critical in the important cleaning process. The cavity-attenuated phase-shift (CAPS) method is ideally suited for performing these important measurements, permitting us to obtain mirrors with reflectivities of $R = 0.99975 \pm 0.00005$.

Preceding Page ^{S/}Blank

ACKNOWLEDGMENT


This work was supported in part by the Air Force Weapons Laboratory under U.S. Air Force Space Division Contract F04701-80-C-0081.

Report No.
ATR-81(8430)-1

DEVELOPMENT OF LASER MIRRORS OF VERY
HIGH REFLECTIVITY USING THE
CAVITY-ATTENUATED PHASE-SHIFT
(CAPS) METHOD


Prepared by


J. M. Herbelin


J. A. McKay

Approved by


N. Cohen, Head
Chemical Kinetics Department


W. P. Thompson, Director
Aerophysics Laboratory

CONTENTS

ABSTRACT.....	iii
ACKNOWLEDGMENT.....	iv
I. INTRODUCTION.....	1
II. HIGH-REFLECTIVITY MIRROR DEVELOPMENT PROCEDURE.....	3
A. Substrate Procurement.....	3
B. Substrate Cleaning.....	3
III. QUARTZ SUBSTRATE SCATTERING MEASUREMENTS.....	7
IV. SUMMARY.....	17
REFERENCES.....	19

FIGURES

1.	Photograph of a Quartz Substrate Before Cleaning as Observed Through a Dark-Field Microscope at 400X Magnification.....	4
2.	Photograph of a Cleaned Quartz Substrate as Observed Through a Dark-Field Microscope at 400X Magnification.....	6
3.	Physical Layout of Optic Train and Phase-Shift Measurement Equipment Used to Measure Average Lifetime of Photons in Optical Resonator.....	8
4.	Two Specific Orientations of Quartz Substrate Sample at Brewster and Normal (Perpendicular) Incidence with Optical Resonator.....	10
5.	Mounting Block and Cover Used for Transporting and Coating Cleaned Substrates.....	12
6.	Alternative Three-Mirror Optical Resonator Configuration for Use with Nontransparent Substrate Mirror Reflectance Measurement at Angle θ	14

I. INTRODUCTION

High-power infrared laser systems and shorter wavelength laser systems based upon electronic transitions have created a need for very-high-reflectivity laser mirrors. This requirement arises from the extremely high photon-flux densities associated with these laser devices and the much lower increases in power per transit between mirrors (gain) of the new electronic transition laser systems compared to the infrared laser systems. As a case in point, for the nitrogen fluoride system currently being studied as a potential laser candidate, the gain is so low that mirrors in excess of 99.95% reflectivity are required for an initial lasing demonstration on a laboratory scale.

We are pleased to report that, with the help of several specialist groups in the field, we have been able to produce mirrors with reflectivities of 99.975% (at a wavelength value near $0.87\ \mu\text{m}$) and that other advances in the state of the art could be achieved if there were a requirement. This accomplishment was possible because we invented a new method for making the critical scattering loss measurements associated with the mirror substrate cleaning process, i.e., the cavity-attenuated phase-shift (CAPS) method.

II. HIGH-REFLECTIVITY MIRROR DEVELOPMENT PROCEDURE

The procedure that we used to produce the high-reflectivity mirrors consists of four basic steps: (1) the procurement of high-quality quartz substrates from a suitable vendor, (2) the cleaning, measurement, and preparation of these substrates, (3) the coating process by which a low-scatter dielectric coating is applied by a qualified supplier, and (4) the measurement of the resultant mirror reflectivity. Since Steps (1) and (3) are performed by suppliers, only Steps (2) and (4) are necessary for ensuring the desired quality.

A. SUBSTRATE PROCUREMENT

The quartz substrates were obtained from General Optics. These were specified to have an RMS smoothness of $< 10 \text{ \AA}$ and be flat and parallel to $< \lambda/4$. These substrates had been cleaned by General Optics. To remove the excess grinding material and waxes used in the polishing process, substantially more cleaning was required. Figure 1 is a photograph taken of one of these General Optics quartz substrates before cleaning. A dark-field microscope at 400X magnification was used. Since the field of view is approximately 0.5 mm, the larger particles are approximately 100 μm with the particles ranging to a detection limit of about 10 μm .

B. SUBSTRATE CLEANING

In our search for a reliable and efficient cleaning procedure, we quickly discovered that each researcher had his own special technique. After some deliberation, we decided to use a "try and see" approach. We started with the special solvent mixture of 1,1,1, trichlorethane and ethanol, which was specially treated to minimize all nonvolatile residues, from Analytical Research



Fig. 1. Photograph of a Quartz Substrate Before Cleaning as Observed Through a Dark-Field Microscope at 400X Magnification. The field of view is 0.5 mm.

Laboratory, Inc. Figure 2 is a photograph of a quartz substrate after being cleaned with this "super solvent." The improvement is obvious. Various cleaning or rubbing techniques were attempted, and microscopic examination followed. We discovered that each technique has its own advantages, and it was difficult to decide which was the most beneficial. It was difficult to correlate the microscope pictures with a quantitative estimate of the scattering. Consequently, we decided to measure the scattering from the surfaces by means of the photon lifetime measurement technique recently developed in this laboratory.¹ Using a modification of this technique we were able to quantitatively measure the scattering and to determine the quickest, easiest, and most reliable technique for cleaning the quartz substrates. The ability to make these quantitative scattering measurements has significantly reduced the labor and equipment costs involved while substantially increasing the reliability of the cleaning procedure.




Fig. 2. Photograph of a Cleaned Quartz Substrate as Observed Through a Dark-Field Microscope at 400X Magnification. The field of view is 0.5 mm.

III. QUARTZ SUBSTRATE SCATTERING MEASUREMENTS

This technique is described in detail elsewhere.¹ A brief description is provided here for convenience. Figure 3 is a schematic of the experimental setup. An amplitude modulated light beam from a suitable source, usually a laser, is directed through one of the slightly transmitting mirrors into the aligned optical cavity comprised of the mirrors and optics to be measured. The dissipation of the light energy within the cavity is caused by absorption, scattering, or transmission at the surfaces of the cavity mirrors and at other optical components within the resonator. Each loss shortens the effective photon lifetime, which is defined as the characteristic time τ for the photon energy to be dissipated to e^{-1} (or 0.34) of its original value. This photon lifetime is determined from a phase shift in the light-beam intensity that has passed through the optical resonator.

The amplitude modulation, which is required to extract time-dependent lifetime data from a steady-state experiment, is conveniently produced by passing the continuous source beam through a piezo-optical birefringence modulator. A linearly polarized photon beam with a $\sin^2(2\pi ft + \phi)$ modulation at $f = 50$ kHz is produced. The resultant phase shift α of the emerging beam is related to the photon lifetime by the simple expression, $\tan(\alpha) = 4\pi f\tau$. Since this lifetime corresponds to some number n of round trips that the photons make within the optical resonator $n = c\tau/2L$, where c is the speed of light, and L is the distance between the mirrors, the overall loss of the optical resonator $1 - R$ and, therefore, the product of the reflectivities $R = R_1R_2$ can be obtained from the simple formula $1 - R = 1/(n + 1)$.





Fig. 3. Physical Layout of Optic Train and Phase Shift Measurement Equipment Used to Measure Average Lifetime of Photons in Optical Resonator

With the use of appropriate combinations of different cavity mirrors and other optical components, each of the respective losses and reflectivities can be determined. The most convenient method of measurement is to use a two-phase lock-in amplifier to measure both the $\sin \alpha$ and $\cos \alpha$, which are, in turn, input into a ratiometer to obtain $\tan \alpha$ directly. For large n 's (n typically ranges from 200 to 2000), this output signal is directly proportional to the cavity lifetime, affording on-line in-situ measurements.

The two ways that the quartz substrate can be placed into the optical cavity to minimize reflectance losses, i.e., at Brewster's angle and perpendicular to the cavity axis, are shown in Fig. 4. At the Brewster's angle, by definition, the reflectance loss for the perpendicular polarized light, which is what is being introduced into the cavity, is theoretically very close to zero. This assumption has been used by other investigators as a means of calibrating their mirror reflectivity measurement methods.² However, we quickly discovered that the substrate placed at the perpendicular angle showed considerably less attenuation of the phase shift and, therefore, less loss than when the same substrate was placed at Brewster's angle. Although the reflectance off the surfaces of the substrate at normal angle is much larger, approximately 4%, it is reflected right back at the mirror and therefore does not represent a loss. However, when the substrate is placed at the Brewster's angle, the light which is plane polarized perpendicular to the plane of incidence is reflected out of the cavity while the light polarized parallel to the plane of incidence is not. Consequently, any rotation of the plane of polarization within the cavity, such as through the birefringence of the quartz substrate itself, results in a much higher loss than would have been

BREWSTER ANGLE (birefringence loss)



TOTAL LOSS (1000 - 2000) ppm

OR (250 - 500) ppm / SURFACE AT 6328 \AA

NORMAL INCIDENCE (no birefringence loss)




Fig. 4. Two Specific Orientations of Quartz Substrate Sample at Brewster and Normal (Perpendicular) Incidence with Optical Resonator

predicted. Thus, the difference between the two measurements of total loss for these two substrate positions affords a very sensitive measurement of the birefringence of the quartz substrate itself. We were also able to measure the small changes in the birefringences that occur when mechanical stress is applied or removed from the substrate.

By means of the cavity-attenuated phase-shift (CAPS) method, we were able to very quickly establish the best (fastest, easiest, and most repeatable, with the lowest amount of scattering) procedure, which consisted of nothing more than a few light wipes, a few hard wipes, followed by a few more light wipes with ordinary lens paper saturated with the "super solvent."

After cleaning, the substrates were spring loaded into the coating mounting block designed to fit into the commercial coating machines (Fig. 5). This block was made from stainless steel that had been specially cleaned to remove all machining oils and greases. It was then preheated to 300°C for 2 hr to remove any residual contamination. The block was not touched by human hands after this. After being loaded with the cleaned substrates, the block was then placed into a special container that formed a vacuum seal. The container was first evacuated and filled with dry filtered nitrogen, then "hand carried" to the supplier for coating. It was returned the same way. Transportation was not trusted to courier services. If dropped, which had happened, the coated substrates could become jammed into the block and could only be removed with the force of a hammer and wood dowel.




Fig. 5. Mounting Block and Cover Used for Transporting and Coating Cleaned Substrates. The container can be evacuated and filled with an inert gas for storage.

Two commercial vendors were investigated to determine the quality of the optical coatings produced. The first of these was CVI, Albuquerque, New Mexico, and the second vendor was Optical Coating Laboratory Incorporated (OCLI). Our criteria were minimum absorption, scattering and transmission losses, and maximum reflectivity. We decided to test the CVI coating quality with a set coated at the 6328-Å wavelength. Using the CAPS method, we measured a reflectivity of $R = 99.89$, which was surprisingly low. We had expected it to be better, or $R = 99.95$ based upon a stipulated transmission loss of 100 ppm and an anticipated scattering loss of 400 ppm at 6328 Å. This expectation had been based upon information supplied to us by V. Sanders, Litton Industries. We then examined the reflectivity as a function of the incident angle by means of the arrangement shown in Fig. 6. We quickly discovered that, at an angle of $\theta = 45$ deg, the reflectivity approached the anticipated higher value. CVI confirmed our suspicions, i.e., that by mistake, the coating had been given a $\theta = 45$ deg maximum reflectivity coating, which is the usual coating for laser gyro mirrors.

We decided to obtain an OCLI coating at the required wavelength of 8742 Å. The same preparation and handling procedures were again employed, and measurement of the final product yielded a value of $R = 99.975$. The calculations used to predict the reflectivity of the final product, are:

1. For the coating, $R = 1 - (T + A + S)$, $T < 100$ ppm, $A \approx 30$ to 300 ppm; $S_C \approx 50$ to 1000 ppm, and $\lambda = 6328$ Å.
2. For the substrate, $S_S \approx 50$ to 500 ppm.




Fig. 6. Alternative Three-Mirror Optical Resonator Configuration for Use with Nontransparent Substrate Mirror Reflectance Measurement at Angle θ

At $\lambda = 8742 \text{ \AA}$, $S = (6328/8742)^2 (S_C + S_S) = 0.52 (50 + 50) = 52 \text{ ppm}$, $A \leq 100 \text{ ppm}$, $T = 100 \text{ ppm}$, $R(8742) \geq 0.99975$ or $(1 - R = 0.00025)$.

These calculations include the range of values for transmission T, absorption A, and scattering S losses arising from the coating and the substrate at the helium-neon wavelength (6328 \AA) for which the most data are available. Wavelength correction of the anticipated scatter from the coating and measured scatter from the substrate is made and combined with the specified absorption and transmission losses to predict the $R = 99.975$ reflectivity mirrors, which we indeed obtained.

IV. SUMMARY

We found that the use of the cavity-attenuated phase-shift (CAPS) method, in conjunction with simple cleaning practices, results in a simplified procedure for producing very-high-reflectivity mirrors. Our substrate cleaning process is a straightforward procedure. It is reasonable to project that a similar application of this CAPS method to the coating processes itself could permit an order of magnitude improvement over present coating limits. The basic reason is that, unlike other methods, the higher the reflectivity of the mirrors being generated, the more sensitive the phase-shift method becomes. Consequently, there is essentially no limit, other than the materials themselves, in producing extremely high reflectivity mirrors.

REFERENCES

1. J. M. Herbelin, J. A. McKay, M. A. Kwok, R. H. Ueunten, D. S. Urevig, D. J. Spencer, and D. J. Benard, "Sensitive measurement of photon lifetime and true reflectances in an optical cavity by a phase shift method," Appl. Opt. 19, 144 (1980).
2. V. Sanders, "High-precision reflectivity measurement technique for low-loss laser mirrors," Appl. Opt. 16, 19 (1977).